

ADVANCED AUDIO WEAPONRY



SURROUND SOUND HEADSET FOR PC GAMING

OWNER'S MANUAL

PSYKO GAMING HEADSET SYSTEM

Welcome to the Psyko Audio Gaming Community, and from everyone at Exeo, congratulations. As a new owner of the Psyko Gaminig Headset System yu are now among a privileged group of gamers experiencing "Advanced Audio Weaponry"!

Visit us at www.exeoent.com to learn more about Psyko Audio and PsykoWave™ technology.

Included in this package:

- 1. Psyko Gaming Headset
- 2. Psvko Amp
- 3. Psyko Mic Boom
- 4. Wall power adapter
- 5. Psyko Owner's Manual



HEADPHONE BREAK-IN PERIOD

You're new Psyko headphones uses seven state-of-the-art electromechanical transducers to reproduce gaming audio with incredible positional accuracy. The Psyko transducer's physical properties will change as the headphones reproduces viscous gunshots and bone jarring explosions. We recommend using your new Psyko headphones for 24 hours before truly accessing their incredible audio qualities.

SETTING UP THE SYSTEM

Connecting the System

- 1. Insert the 3.5mm plugs from the Psyko Gaming Headset into the appropriately colored Psyko Amp jacks.
- Insert the 3.5mm plugs from the Psyko Amp into the matching colored jacks on the sound card (on-board, add-on, or USB).
- 3. Optionally, insert the Psyko Mic Boom plug into the jack on the underside of the right ear cup.
- 4. Insert the power adapter into the Psyko Amp and plug the unit into a convenient wall outlet.

Sound Card Connection





Power Adapter Plug In



USING THE PSYKO GAMING HEADSET

- 1. Headset is worn on the head with the wire on the left side.
- To adjust the headset slide the ear cups up and down along the WaveGuides to an appropriate and comfortable position.





3. The ear cup windows are adjustable and can open for ventilation or for listening to the external environment.



TURNING ON THE PSYKO AMP

- 1. To turn on the Psyko Amp rotate the volune control knob clockwise (larger knob).
- With a sound PC source activated continue turning the volume control knob clockwise until a comfortable listening level is reached.

ADJUSTING BASS & DIRECTIONALITY

On the left side of the bass control knob (smaller knob) is a "dir" option and on the right is a "bass" setting. As the knob is turned towards the "bass" option, more bass is experienced. As the knob is turned towards the "dir" option, less bass but more directionality is experienced (i.e. Increase the ability to perceive where sounds are coming from).

TURNING ON 5.1 SURROUND SOUND

Though the Psyko Gaming Headset System is a plug and play system that does not require external software, the system does require the 5.1 surround sound to be enabled on both the computer and the video game being played.

The following instructions will show how to enable 5.1 surround sound on a computer and video game.

WINDOWS XP

- From the Start Menu, select Control Panel
- 2. In the ControlPanel select Sounds and Audio Devices
- 3. In the Volume tab choose Advanced in the Speaker Settings section
- 4. In the Speaker Setup pull down menu select 5.1 Surround Sound Speakers and click OK
- 5. In the Voice tab choose the appropriate device, in the Device Playback menu.

WINDOWS VISTA & WINDOWS 7

Vista and Windows 7 only allow modifications to sound settings is a 5.1 capable application has been selected in the sounds tool.

- 1. From the Start Menu, select Control Panel
- 2. In the Control Panel, select Sound
- Choose the Sound Card
- Right click, choose Properties
- 5. Select Enhancements tab, check Disable All Enhancements box and click OK
- Right click, choose Configure Speakers
- Choose 5.1 Surround and then click Test. Press any speaker to hear sounds from that speaker. This is a good way to ensure the Psyko Gaming Headset is properly connected and configured.

MAC


- 1. Click on the MAC Icon
- 2. Select System Preferences
- 3. Select Sound
- 4. Select Output tab
- 5. Select the 5.1 sound card being used

VIDEO GAME SETTINGS

- 1. Click on Options
- 2. Select Sound or Audio
- 3. Change sound source to 5.1 Surround Sound

TROUBLESHOOTING

There are six LEDs on the Psyko Amp. The LEDs are a useful tool for visual confirmation of which channels are playing.



Note: The bottom middle LED indicates power and will remain lit as long as power is supplied to the unit and the unit is turned on.

*Color Codes for Amp and Sound Card channel plugs

GREEN: Front L/R BLACK: Rear L/R

GOLD: C/Sub PINK: Mic

I IMITED WARRANTY

1 - YEAR I IMITED WARRANTY

Your Psyko Gaming Headset System is warranted against manufacture defects in materials and workmanship for a period of one (1) year from the date of original retail purchase. Exeo at its option will (1) repair the product at no charge using new or refubished parts. (2) exchange the product with a functional equivalent product that is new or refurbished. This does not mean you can abuse your headphones and expect warranty service. We do not cover normal wear and tear, scratches, loss or theft. This warranty excludes damages resulting from abuse, accident, modifications or other causes that are not defects in materials and workmanship. Any customization of your product will void your warranty.

Any recovery is limited to the original purchase price. No other person is authorized to modify this limited warranty. Your seller is responsible for any other warranty.

To obtain warranty service, contact Exeo Entertainment using the information provided at: support.exeoent.com

WARNINGS & CAUTIONS

Avoid hearing damage.

Volume should always be adjusted to a safe and comfortable level. The louder the volume the shorter your experience with the headset should be. Listening to the headset at high volume levels may result in hearing loss. If you or any other user ever experience ringing in the ears or cannot hear individuals while they speak in a normal setting, stop listening to the headset and visit a doctor.

Never connect the AC power to a different voltage!

Never use any AC adapter other than the one supplied!

Do not use the system near water!

Technical Assistance can be obtained by visiting the Support page at: support.execent.com

PRODUCT REGISTRATION

Register your headset at: support.execent.com



4478 Wagon Trail Ave Las Veags, NV 89118 702-361-3188 www.exeoent.com